

Kelly HPM High Power Full Bridge Permanent Magnet DC Motor Controller User's Manual

**HPM72601
HPM72801
HPM12401
HPM12601
HPM12801
HPM14301
HPM14501
HPM14701**

Contents

Chapter1	Introduction.....	2
1.1	Overview.....	2
Chapter2	Main Features and Specifications.....	3
2.1	General functions.....	3
2.2	Features.....	4
2.3	Specifications.....	4
Chapter 3	Wiring and Installation.....	5
3.1	Mounting the Controller.....	5
3.2	Connections.....	8
3.3	Installation Checklist.....	12
Chapter 4	Maintenance.....	12
4.1	Cleaning.....	13
4.2	Configuration.....	13
Table 1:	LED CODES.....	14
Contact Us:	15

Chapter1 Introduction

1.1 Overview

This manual introduces the Kelly HPM motor controllers' features, their installation and their maintenance. Read the manual carefully and thoroughly before using the controller. If you have any questions, please contact the support center of Kelly Controls.

Kelly's programmable motor controllers provide high efficient, smooth and quiet controls for electric vehicles like golf carts, forklifts and hybrid vehicles, as well as electric boats and industrial motor speed control. It uses high power MOSFET's and, PWM to achieve efficiencies of up to 99% in most cases. A powerful microprocessor brings in comprehensive and precise control to the controllers. It also allows users to adjust parameters, conduct tests, and obtain diagnostic information quickly and easily.

Kelly's HPM high power motor controller is full bridge or 4 quadrant controller. It provides fast and reliable electronic direction control. There is no arc, spark, or life limit on motor direction changes.

Chapter2 Main Features and Specifications

2.1 General functions

- (1) Extended fault detection and protection. The LED flashing pattern indicates the fault sources. Green LED indicates normal operation. Controller will shut down in some fault conditions.
- (2) Monitoring battery voltage. It will stop driving if the battery voltage is too high and it will progressively cut back motor drive power as battery voltage drops until it cuts out altogether at the preset "Low Battery Voltage" setting.
- (3) Built-in current loop and over current protection.
- (4) Configurable motor temperature protection range.
- (5) Current cutback at low temperature and high temperature to protect battery and controller.
The current begins to ramp down at 90 °C case temperature, shutting down at 100 °C.
- (6) Two RS232 ports. Both can be used for configuration.
- (7) Configurable and programmable with a host computer through RS232 or USB. Provide free GUI which can run on Windows XP/2000, Windows 7 and Vista (recommend using Kelly Standard USB To RS232 Converter).
- (8) Provision of a +5 volt output to supply various kinds of sensors, including Hall effect type.
- (9) 4 switch inputs which are activated by connection to Ground. Default to throttle switch, brake switch, reversing switch and Boost/Economy switch input.
- (10) 3 analog 0-5V inputs that default to throttle input, brake input and motor temperature input.
- (11) Pulsed reverse alarm output.
- (12) Main contactor driver. Cutting off the power if any fault is detected.
- (13) Current meter to display both drive and regen current. Save shunt.
- (14) Configurable boost switch. Enables the maximum output power achievable if the switch is turned on.
- (15) Configurable economy switch. Limits the maximum current to half if the switch is turned on.
- (16) Maximum reverse power is configurable to half power.
- (17) Enhanced regen brake function. A novel ABS technique provides powerful and smooth regen.
- (18) Configurable 12V brake signal input, in lieu of motor temperature sensor.
- (19) Optional joystick throttle. A bi-symmetrical 0-5V signal for both forwarding and reversing.
- (20) Configurable motor over-temperature detection and protection with the recommended thermistor KTY84-130.
- (21) Using battery-powered.
- (22) Optional CAN bus.
- (23) Supply voltage 8V-30V.

2.2 Features

- Opto-isolated technology achieve stability.
- Intelligence with powerful microprocessor.
- Synchronous rectification, ultra low drop, and fast PWM to achieve very high efficiency.
- Electronic reversing, no reversing contactor needed, fast direction change, high reliability and efficiency, low noise, no arc, no wearing, no life limit, easy maintenance.
- Voltage monitoring on voltage source 12V and 5V.
- Current limit and torque control. Configurable torque mode and speed mode.
- Low EMC.
- LED fault code.
- Battery protection: current cutback, warning and shutdown at configurable high and low battery voltage.
- Rugged aluminum housing for maximum heat dissipation and harsh environment. Support fan or water cooling.
- Rugged high current terminals, and rugged aviation connectors for small signal.
- Thermal protection: current cut back, warning and shutdown at high temperature.
- Configurable high pedal protection: the controller will not work if high throttle is detected at power on.
- Brake switch is used to start regen.
- Support three modes of regenerative braking: brake switch regen, release throttle regen, 0-5V analog signal variable regen.
- An RS232 port allows for configuration, programming and software upgrades using the free Windows GUI with your PC.
- Standard PC/Laptop computer is used to do programming. No special tools needed.
- User program provided. Easy to use. No cost to customers.
- No adjustment.

2.3 Specifications

- Frequency of Operation: 16.6kHz.
- Standby Battery Current depending on the model: usually less than 2mA.
- 5V Sensor Supply Current: 40mA.
- Controller supply voltage range, PWR, 8 to 30V (24V preferred)
- Controller input power, PWR: less than 10W.
- Standard Throttle Input: 0-5 Volts(3-wire resistive pot), 1-4 Volts(hall active throttle).
- Analog Brake and Throttle Input: 0-5 Volts.
- Reverse Alarm, Main Contactor Coil Driver, Meter.
- Full Power Temperature Range: 0 °C to 50 °C (controller case temperature).
- Operating Temperature Range: -30 °C to 90 °C ,100 °C shutdown(controller case temperature).
- Motor Current Limit, 1 minutes: 300A-800A depending on the model.
- Motor Current Limit, continuous:135A-400A, depending on the model.

- Max Battery Current :Configurable.

Kelly Full Bridge Permanent Magnet DC Motor Controller				
Model	1 minute Current	Continuous Current	Rated Voltage	Regen
HPM72601	600A	300A	72V	Yes
HPM72801	800A	400A	72V	Yes
HPM12401	400A	200A	120V	Yes
HPM12601	600A	300A	120V	Yes
HPM12801	800A	400A	120V	Yes
HPM14301	300A	135A	144V	Yes
HPM14501	500A	225A	144V	Yes
HPM14701	700A	315A	144V	Yes
Female plugs of J1&J2 will be shipped for free.				

Chapter 3 Wiring and Installation

3.1 Mounting the Controller

The controller can be oriented in any position which should be as clean and dry as possible, if necessary, shielded with a cover to protect it from water and contaminants.

To ensure full rated output power, the controller should be fastened to a clean, flat metal surface with four or six screws. Applying silicon grease or some other thermal conductive material to contact surface will enhance thermal performance.

Proper heat sinking and airflow are vital to achieve the full power capability of the controller.

The case outline and mounting holes' dimensions are shown in Figure 1 and 2.

Caution:

- **RUNAWAYS — Some conditions could cause the vehicle to run out of control.** Disconnect the motor, or jack up the vehicle, and get the drive wheels off the ground before attempting any work on the motor control circuitry.
- **HIGH CURRENT ARCS — Electric vehicle batteries can supply very high power, and arcs can occur if they are short circuit.** Always turn off the battery circuit before working on the motor control circuit. Wear safety glasses, and use properly insulated tools to prevent short circuit.




Figure 1: Height: 84 millimeters
Length: 204 millimeters

Controller models with above dimension: HPM72601, HPM72801, HPM12401
HPM12601, HPM14301, HPM14501




Figure 2: Height: 84 millimeters
Length: 286 millimeters

Controller models with above dimension: HPM12801, HPM14701

3.2 Connections

3.2.1 Front and Back Panels of PM Motor Controller:

Four metal bars and two plugs (J1, J2) are provided for connecting to the battery, motor and control signals in the front and back panels of the controller shown as Figure 3 and 4




Figure 3: Front panel of HPM motor controller

B+: Battery positive

B-: Battery negative

M+: armature positive

M-: armature negative





Figure 4: Back panel of HPM motor controller**Figure 5: The connecting diagram of J1 and J2**

J1 Pin Definition

- 1- PWR: Controller power supply (output).
- 2- Current meter. <200mA
- 3- Main contactor driver. <2A
- 4- Alarm: To drive reverse beeper, <200mA.
- 5- GND: Signal return
- 6- Green LED: Running indication
- 7- GND: Signal return
- 8- Reserved
- 9- Reserved
- 10- CAN bus high. Optional
- 11- CAN bus low. Optional
- 12- Reserved
- 13- GND: Signal return, or power supply ground
- 14- Red LED: Fault code.

J2 Pin Definition

- 1- PWR: Controller power supply (input)
- 2- GND: Signal return, or power supply ground
- 3- GND: Signal return
- 4- Motor temperature input.
- 5- Throttle analog input, 0-5V
- 6- Brake analog input, 0-5V
- 7- 5V: 5V supply output. <50mA
- 8- Micro_SW: Throttle switch input
- 9- Reversing switch input
- 10- Brake switch input
- 11- Reserved
- 12- Reserved
- 13- Reserved
- 14- GND: Signal return


Notes:

1. All RTN and GND pins are internally connected, but isolated from B-.
2. Two PWR pins, J1-1 and J2-1, are internally connected. It's recommended to use J1-1 to supply peripherals like alarm and contactor. Twist peripheral wires with PWR is the preferred for EMC.
3. Kelly Ammeter positive connect to 5V power supply of controller, negative to J1-2.
4. Switch to ground is active. Open switch is inactive.

Caution:

- Do not apply power until you are certain the controller wiring is correct and has been double checked. Wiring faults will damage the controller.
- Ensure that the B- wiring is securely and properly connected before applying power.
- The preferred connection of the system contactor or circuit breaker is in series with the B+ line.
- All contactors or circuit breakers in the B+ line must have precharge resistors across their contacts. Lack of even one of these precharge resistors may severely damage the controller at switch-on.

3.2.2 Standard Wiring of HPM Motor Controller



NOTE: Potentiometer can be used to output 0-5V.
 Please securely wire B- before any other wiring. Never put contactor or break on B-. Don't connect RTN to B-.
 * CAN bus is depopulated by default.
 ** When you connect an external LED, the LED front panel brightness will be reduced.
 *** Thermistor is optional item, default to KTY84-130.
 **** 12V Isolated DC/DC Converter Is Preferred.

Figure 6: HPM motor controller standard wiring

3.2.3 Communication Port

A RS232 port of controller is provided to communicate with host computer for calibration and configuration.




Figure 7: standard RS232 interface

3.3 Installation Checklist

Before operating the vehicle, complete the following checkout procedures. Use LED code as a reference as listed in Table 1.

Caution:

- Put the vehicle up on blocks to get the drive wheels off the ground before beginning these tests.
- Do not allow anyone to stand directly in front of or behind the vehicle during the checkout.
- Make sure the PWR switch and the brake is off
- Use well-insulated tools.

- Make sure the wire is connected correctly.
- Turn on the PWR switch, the Red flashes once and the Green is off. After the start-up delay, normally the Red will stay off and the Green will turn on. If there is error, the Red LED will flash for fault codes.
If the S/N less: 11xxxxxx: Turn on the PWR switch, the Red flashes once and the Green is on. Normally, the Red will stay off. If there is error, the Red LED will flash for fault codes.
- The fault code will be detected automatically at restart.
- With the brake switch open, select a direction and operate the throttle. The motor should spin in the selected direction. Verify wiring or voltage and the fuse if it does not. The motor should run faster with increasing throttle. If not, refer to the Table 1 LED code, and correct the fault as determined by the fault code.
- Take the vehicle off the blocks and drive it in a clear area. It should have smooth acceleration and good top speed.

Chapter 4 Maintenance

There are no user-serviceable parts inside the controllers. Do not attempt to open the controller as this will void your warranty. However, periodic, exterior cleaning of the controller should be carried out.

The controller is a high powered device. When working with any battery powered vehicle, proper safety precautions should be taken that include, but are not limited to, proper training, wearing eye protection, avoidance of loose clothing, hair and jewelry. Always use insulated tools.

4.1 Cleaning

Although the controller requires virtually no maintenance after properly installation, the following minor maintenance is recommended in certain applications.

- Remove power by disconnecting the battery, starting with battery positive, providing that the battery negative is not earthed. If battery negative is earthed, disconnect that first.
- Discharge the capacitors in the controller by connecting a load (such as a contactor coil, resistor or a horn) across the controller's B+ and B- terminals.
- Remove any dirt or corrosion from the bus bar area. The controller should be wiped down with a moist rag. Make sure that the controller is dry before reconnecting the battery.
- Make sure the connections to the bus bars, if fitted, are tight. To avoid physically stressing the bus bars use two, well-insulated wrenches.

4.2 Configuration

You can configure the controller with a host computer through either an RS232 or USB port.

- Disconnect motor wiring from controller.
- Do not connect B+, throttle and so on. The controller may display fault code in some conditions, but it doesn't affect programming or configuration.
- Use a straight through RS232 cable or Kelly USB To RS232 Converter to connect to a host computer. Provide 10V-30V (either J2 pin1 or J1 pin1) to PWR. Wire power supply return to any RTN pin, isolated from B-.

Download the free configuration software from:

<http://www.kellycontroller.com/support.php>

Caution:

- Make certain that the motor is disconnected before trying to run the Configuration Software!
- Configuration software will be regularly updated and published on the website. Please Update your Configuration Software regularly. You must uninstall the older version before updating.

Table 1: LED CODES

Green LED Code

LED Code	Explanation	Solution
Green Off	No power or switched off	1. Check if all wires are correct. 2. Check fuse and power supply.
Green On	Normal operation	That's great! You got solution!
Green & Red are both On		1. Software still upgrading. 2. Supply voltage too low or battery too high 3. The controller is damaged. Contact Kelly about a warranty repair.

Red LED Code

1,2	¤ ¤¤	Over voltage error	1. Battery voltage is too high for the controller. Check battery volts and configuration. 2. Regeneration over-voltage. Controller will have cut back or stopped regen. 3. This only accurate to \pm 2% upon Overvoltage setting.
1,3	¤ ¤¤¤	Low voltage error	1. The controller will clear after 5 seconds if battery volts returns to normal. 2. Check battery volts & recharge if required.
1,4	¤ ¤¤¤¤	Over temperature warning	1. Controller case temperature is above 90°C. Current will be limited. Reduce controller loading or switch Off until controller cools down. 2. Clean or improve heatsink or fan.
2,2	¤¤ ¤¤	Internal voltage fault	1. Measure that B+ & PWR are correct when measured to B- or RTN. 2. There may be excessive load on the +5V supply caused by too low a value of Regen or throttle potentiometers or incorrect wiring. 3. Controller is damaged. Contact Kelly about a warranty repair.
2,3	¤¤ ¤¤¤	Over temperature	The controller temperature has exceeded 100 °C . The controller will be stopped but will restart when temperature falls below 80°C.
2,4	¤¤ ¤¤¤¤	Throttle error at power up	Throttle signal is higher than the preset 'dead zone' at Power On. Fault clears when throttle is released.
3,1	¤¤¤ ¤	Frequent reset	May be caused by over-voltage, bad motor

			intermittent earthing problem, bad wiring, etc.
3,2	xxxx xx	Internal reset	May be caused by some transient fault condition like a temporary over-current, momentarily high or low battery voltage. This can happen during normal operation.
3,3	xxxx xxxx	Hall throttle is open or short-circuit	When the throttle is repaired, a restart will clear the fault.
3,4	xxxx xxxx	Non-zero throttle on direction change	Controller won't allow a direction change unless the throttle or speed is at zero. Fault clears when throttle is released.
4,1	xxxxx x	Regen or Start-up over-voltage	Motor drive is disabled if an over-voltage is detected at start-up or during regen. The voltage threshold detection level is set during configuration. The max threshold is about 1.25 times of controller rated voltage. I.e. you may set threshold lower than 60V for 48V controller.
4, 3	xxxxx xxx	Motor over-temperature	Motor temperature has exceeded the configured maximum. The controller will shut down until the motor temperature cools down.
The Red LED flashes once at power on as a confidence check and then normally stays Off. "1, 2" means the Red flashes once and after a second pause, flashes twice. The pause time between multiple flash code groups is two seconds.			

Contact Us:

Kelly Controls

Home Page:

<http://www.kellycontroller.com>

E-mail:

support@kellycontroller.com

Phone:

(01) 224 637 5092