



Note: By default both motors run on the opposite direction. You may pull out Pin2 of the assembly and insert Pin9 if you need both motors run on the same direction

See From Front Side



							KELLY CONTROLS, LLC		
Mark	Subarea	Signatory	Date	06/25/2009					
Design		Stand		modification	Number	Proportion			
Assessor							V1.0		
Technics		Authorize					Sum		

Dual KEB/KBL Controller Assembly Wiring Diagram